




Gently remove the ribbon cable (orange in the picture on your left).

Carefully erase the area shown in the image below



Then put the cable back on and you're done!